JET-PRO® for Active Wear Heat Transfer Paper

JET-PRO® for Active Wear Heat Transfer Papers are designed for the heat transfer of photos and images using ink jet printers to light colored synthetic garments including On synthetic fibers this product has superior wash stretchy performance fabrics. fastness and almost no hand.

PRINTING

- 1. Mirror the image.
- 2. Load the paper so that the image will appear on the coated side of the
- 3. Trim away the unprinted areas of the transfer if desired.



Using a Commercial Heat Press

- 1. Place the transfer on top of the garment with the image side down. Press: 20-25 seconds at 375°F using heavy pressure. Lower temperatures and times may result in better transfers on some fabrics.
- 2. Remove paper while still hot. This fabric will be very hot please use caution.

(Product is not recommended for 100% cotton.)



INK JET



WHITE and LIGHT COLOR



375°

Heavy

TEMPERATURE PRESSURE 20-25 seconds

WASHING INSTRUCTIONS

Turn garment inside out and wash in cold water using a mild detergent. Do not use bleach. Dry on low heat setting. Do not iron directly on the transferred area.

STORAGE AND HANDLING OF JET-PRO® for Active Wear Heat Transfer Papers

Store JET-PRO® for Active Wear Heat Transfer Papers in a cool, dry area and do not remove from carton or poly bag until you are ready to use.

Refer to www.technicalproducts.com/heattransfer for information on our entire line of heat transfer products.

IMPORTANT

We thoroughly test each of our products on various substrates using different transfer equipment. However, it is impossible for us to duplicate all variables using all substrates and transfer equipment. Therefore, it is essential that you test the paper prior to production using your and variables using an abustrate material. Heat presses vary in accuracy. Conduct tests to determine the best time and temperature to use with your equipment. Please keep in mind that the Seller's and Manufacturer's maximum obligation shall be to replace any paper that has proven to be defective. Neither the Seller nor the Manufacturer shall be liable for any injury, direct or consequential, arising out of the use of, or inability to use this paper.