TransferWear Premium

TransferWear Premium Papers are designed for the heat transfer of photos and images using fuser oil printers to T-shirts, sweatshirts, mousepads, coasters, puzzles, binders, scrapbook covers, padfolios, art papers, leather, magnets, wood veneer and nylon. Choose garments that have a tight weave. This is particularly important when transferring to sweatshirts.

PRINTING

- 1. Mirror the image.
- 2. Load the paper so that the image will appear on the coated side of the paper.
- 3. PHOTO-TRANS® PLUS Paper should be fed into the copier or printer with the short dimension first (grain long).
- 4. Trim away the unprinted areas of the transfer if desired.



Using a Commercial Heat Press

1. Place the transfer on top of the garment with the image side down.

Press:

15 seconds at 375°F using heavy pressure.

2. Peel while still hot.



LASER FUSER OIL ONLY



WHITE and LIGHT COLOR



TEMPERATURE 375°
PRESSURE Heavy
TIME 15 seconds

WASHING INSTRUCTIONS

Turn garment inside out and wash in cold water using a mild detergent. Do not use bleach. Dry on low heat setting. Do not iron directly on the transferred area.

STORAGE AND HANDLING OF PHOTO-TRANS® PLUS HEAT TRANSFER PAPERS

Store PHOTO-TRANS $^{\circ}$ PLUS Papers in a cool, dry area and do not remove from carton or poly bag until you are ready to use.

Refer to <u>www.technicalproducts.com/heattransfer</u> for information on our entire line of heat transfer products.

IMPORTANT

We thoroughly test each of our products on various substrates using different transfer equipment. However, it is impossible for us to duplicate all variables using all substrates and transfer equipment. Therefore, it is essential that you test the paper prior to production using your equipment, methods, and substrate material. Heat presses vary in accuracy. Conduct tests to determine the best time and temperature to use with your equipment. Please keep in mind that the Seller's and Manufacturer's maximum obligation shall be to replace any paper that has proven to be defective. Neither the Seller nor the Manufacturer shall be liable for any injury, direct or consequential, arising out of the use of, or inability to use this paper.